

50mm Horn-Shaped Lamp Cover

User Manual — Chrome / Gold Finish, Iron, Electroplated

Model: 50x14mm Horn Cover | Center Hole: 10mm

1. PRODUCT OVERVIEW

The 50mm Horn-Shaped Lamp Cover is a decorative and protective lighting hardware accessory used on pendant lamps, ceiling lamps, wall lamps and table lamps. Its classic horn shape gives fixtures a retro, elegant look while covering and protecting the lamp wiring area. It is ideal for lamp repair, restoration, DIY lamp making and upgrading existing fixtures. Available in Chrome (silver) and Gold (brass) electroplated finishes.

2. TECHNICAL SPECIFICATIONS

Product Type	Lamp Cover / Horn Shade Cap
Diameter	50mm
Height	14mm
Center Hole Diameter	10mm
Material	Iron
Surface Finish	Electroplated (Chrome or Gold)
Color Options	Chrome (Silver), Gold (Brass)
Weight	Approx. 20g (per piece)
Installation	Mechanical mounting via center hole
Electrical Rating	N/A (non-electrical accessory)

3. PACKAGE CONTENTS

1 x 50mm Horn-Shaped Lamp Cover

4. INSTALLATION INSTRUCTIONS

Step 1: Confirm the cover diameter and center hole (50mm / 10mm) match your lamp stem or mounting hardware before installation.

Step 2: Choose the desired position — lamp shade top, canopy area, or fixture base.

Step 3: Slide the cover over the lamp stem or rod through the 10mm center hole.

Step 4: Secure it in place with the existing lamp nut, collar or fixing ring (not included).

Step 5: Check that the cover sits firmly and evenly; adjust the position if needed.

Note: This is a mechanical accessory only — no electrical wiring is required. Always ensure the lamp is unplugged or power is off while handling any lighting fixture.

5. WIRING DIAGRAM

NOT APPLICABLE — this product is a non-electrical mounting accessory. It requires no wiring connection.

6. COLOR STATUS RECOMMENDATIONS

NOT APPLICABLE — this product is not a signal light.

7. MAINTENANCE AND CARE

Wipe with a soft dry cloth to remove dust and fingerprints.

For stubborn dirt, use a slightly damp cloth and dry immediately; never use abrasive cleaners or metal brushes.

Avoid harsh chemicals, acids or alkaline cleaners which may damage the electroplated surface.

Store in a dry, ventilated place to prevent tarnishing or rust.

Inspect periodically for loosened fittings and tighten when necessary.

8. SAFETY WARNINGS

- Always turn off the power or unplug the lamp before installation or removal.
- Only use the cover with compatible lamp hardware matching the 50mm diameter and 10mm center hole.
- Do not overload, drop or subject the cover to strong impact.
- Do not use on high-temperature surfaces or near open flames.
- Keep small parts away from children — choking hazard.
- If the electroplated surface is damaged, replace the cover to avoid sharp edges.

9. TROUBLESHOOTING

Problem	Solution
Cover does not fit the lamp stem	Confirm the center hole is 10mm and the stem diameter is compatible; use a
Cover feels loose after installation	Tighten the fixing nut or collar; add a rubber gasket if necessary.
Surface appears dull or spotted	Clean with a soft dry cloth; avoid moisture and harsh chemicals.
Scratches on the finish	Handle with care during installation; use gloves to prevent scratches.

10. WARRANTY POLICY

This product is covered by a 1-year warranty against manufacturing defects (including peeling or defective electroplating under normal use). The warranty does not cover damage caused by misuse, improper installation, chemical corrosion, physical impact or normal wear and tear.

11. AFTER-SALES SERVICE

For any questions or support, please contact:

Jude — Tel/WhatsApp: +86-15915305795

Email: sales01@birtechnology.com

Website: www.cnclight.com

We respond within 24 hours on business days.